



Jumbo Tile - Flexible PVC flooring system using heavy duty interlocking tiles -
For the quick covering of large floor areas in domestic or commercial premises

COMPONENTS

Interlocking flexible PVC Jumbo Tiles
450mm x 450mm x 7mm thick
(18" x 18")



Ramped Edge Piece
450mm x 76mm
(18" x 3")



90° Corner Piece
76mm wide/radius
(3")

FLEXIBLE PVC TILE INSTALLATION

Flexible PVC tiles are quick and simple to install. Simply lay flat, locate the interlocking edges, press them together and you're away. No glue. No adhesive. The following instructions are for the 450mm (18") square flexible PVC tiles with uniform dove tail edge joints.

SITE PREPARATION

The flexible PVC tiles are meant to be installed on a clean, flat and solid surface. Sweep the floor to remove any stones or other debris before you begin. In some instances it may be necessary to patch or fill holes in the substrate and grind down any significant protrusions that may interfere with installing the PVC tiles on a flat surface. Some rough finished concrete floors may benefit from being treated with a self levelling compound or similar prior to fitting the floor covering.

Note: While the flexible PVC tiles will follow the level of uneven floors significant dips may cause the edges to come apart. It is also advisable to leave a gap of approx. 5-10mm between the edge of the tile floor and the walls to accommodate thermal expansion of the tile. If required, after fitting the floor this gap can be filled with a flexible mastic or covered up using the Dynotile skirting.

INSTALLATION

Having calculated the correct quantity of tiles required and planned your design, start in either the centre of the room or for garages/warehouses etc with doors and shutters start in the middle of the front entrance and lay a column of tiles towards the centre of the room.

Continue fitting the tiles by radiating towards the four sides of the room. The perimeter rows and columns of tiles will need to be cut in to suit. Cutting tiles can be easily done with a Stanley knife - remember that as the tile edges are universal off cuts from one wall can often be used along the opposite or adjacent wall. As previously mentioned, leave an expansion gap of approx 5-10mm when cutting in to the walls - the same applies when cutting in around columns etc.

Finally across the room entrance or around the exposed edges of the floor fit the ramped edge pieces and any necessary 90° corner pieces.

The floor is complete and now ready for use. Remember as flexible PVC products have a slight 'memory', the floor may take a couple of days to bed in which means the interlocking edges may require time to sit completely flush.

MAINTENANCE

Day-to-day maintenance is performed by sweeping with a soft broom and spot cleaning any stains or marks. Solvent-based solutions can usually be used to clean stubborn areas without harming the flooring though applying to a small test area is advisable. Occasional cleaning with a water and degreaser solution such as Dynotile Citrus Cleaner will also help to keep the floor looking its best.

